



Technical Bulletin

2400 Boston Street, Suite 200, Baltimore, Maryland 21224

Phone: 410-675-2100 or 800-543-3840

Revised: 10/5/06

DAP® Tub Surround & Shower Wall Construction Adhesive – VOC Compliant

- Quick-grab formula
- Steam, heat and water resistant
- Strong, permanent bond
- Low odor

Packaging: 10.3 fl. oz. (305 mL)
Color: Clear
UPC Number: 70798 27420, 70798 27020

Company Identification:

Manufacturer: DAP Inc., 2400 Boston St., Baltimore, Maryland 21224
Usage Information: DAP HELPLINE: 888-DAP-TIPS, 9:00 am to 7:00 pm EST.
Order Information: 800-327-3339
Fax Number: 410-534-2650
Also, visit the DAP website at www.dap.com.

Product Description:

DAP® Tub Surround & Shower Wall VOC Compliant Construction Adhesive is VOC compliant and specially formulated for the installation of tub surrounds and shower wall enclosures to a variety of substrates. Quick-grab formula provides a strong steam, heat and water resistant bond. Won't harm most plastic tub surrounds and shower walls. It is low odor and cleans up easily with soap and water. Interior use.

Suggested Uses:

Bonds most plastic, fiberglass and foamback tub surrounds and shower wall enclosures to drywall, plywood, greenboard, and cement backerboard.

For Best Results:

- Apply in temperatures between 40°F and 90°F.
- Not recommended for applications other than tub surround and shower wall installation.
- Not recommended for thinner or translucent tub surrounds.

Surface Preparation & Application:

INSTRUCTIONS: Before beginning, carefully read and follow the tub surround/shower wall manufacturer's directions.

1. Surfaces must be clean, dry, structurally sound and free of foreign material.
2. Precut and fit materials before applying adhesive.
3. Trim nozzle to 1/8" bead size.
4. Puncture inner foil seal.

5. Load cartridge into caulking gun.
6. Apply a continuous 1/8" bead to the back of panel according to the tub surround manufacturer's installation instructions.
7. If called for by tub surround manufacturer's instructions, spread adhesive evenly with v-notch trowel.
8. Within 15 minutes, position and press panel firmly into place.
9. For proper installation, it is recommended that each panel be vented. Vent the panel by pulling the panel away from the wall for 3 to 5 minutes, then firmly press the panel back into place. If necessary, use masking tape to temporarily secure panel edges until adhesive has set. Failure to vent may result in damage to tub surround.
10. Allow to dry for 24 hours before exposing to water or moisture.

Physical & Chemical Characteristics:

Vehicle:	Acrylic Polymer
Volatile:	Water
Flash Point:	Greater than 200°F
Solids:	58-61% by weight
Weight/Gallon:	8.9 lbs.
Odor:	Very slight ammonia
Color:	White while wet, dries clear
Consistency:	Paste
Application Temperature Range:	Great than 40°F
Open Time:	20 minutes minimum
Freeze/Thaw Stability:	Stable
Coverage:	1/8" bead covers 126 linear feet
Shelf Life:	1 Year
MSDS No.:	000 10002 002

Clean Up & Storage:

Use warm, soapy water to clean up excess wet adhesive from surface, hands and tools. Cured adhesive must be cut or scraped away, being careful not to damage tub surround. Do not use solvents on tub surrounds. Product has a 12 month shelf life when unopened and stored in a cool, dry place. Follow original directions for reuse.

Safety:

See product label and Material Safety Data Sheet for safety information. You can request an MSD sheet by visiting our website at www.dap.com or calling 888-DAP-TIPS.

Satisfaction Guaranteed:

If not satisfied with product performance when used as directed, return used container and sales receipt to DAP Inc., Technical Customer Service, 2400 Boston St., Suite 200, Baltimore, MD, 21224, for product replacement or sales price refund. DAP will not be liable for incidental or consequential damage.